

**ARZUM**<sup>®</sup>

## MIXSET PLUS

AR 1002 ÇUBUK  
BLENDER SETİ

KULLANMA KILAVUZU

ARZUM<sup>®</sup>  
MIXSET PLUS

**550 W**

**3 YIL**  
ARZUM GARANTİSİ<sup>®</sup>

## MIXSET PLUS AR 1002 HAND BLENDER SET



- |  |   |
|--|---|
| 1- Motor (Main body)                       | 7- Beater adapter                               |
| 2- Operation button                        | 8- Beaters                                      |
| 3- Adapter                                 | 9- Metal grinding and mixing accessory          |
| 4- Bowl with a capacity of 700 ml.         | 10- Blade                                       |
| 5- Stainless steel blade with double-sided | 11- Measuring beaker with a capacity of 800 ml. |
| 6- Anti-slipping base                      |   |

We thank you for having selected the **Arzum** brand **Hand Blender Set**. This product as well is one of those offered to you to make life easier for you.

In order to obtain utmost output from your appliance, please read carefully this user's manual and save it for further use.

## IMPORTANT SAFEGUARDS

When using an electric appliance the basic safety measures should always be observed, including:

- Make sure that the voltage indicated on the **Arzum Mixset Plus Hand Blender Set** corresponds with the mains voltage in your home. Our company shall not be held liable for any failures owing to any discrepancy and such failures shall not be covered by the guarantee.
- Your device is for household use only. Do not use outdoors for commercial or industrial purposes.
- Keep the appliance away from and out of the reach of children.

• This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

• Always disconnect the blender from the supply if it is left unattended and before assembling, disassembling or cleaning;

• Do not allow children to use the blender without supervision.

- To prevent harming your appliance do not use extension cords that supply insufficient current.

- **NEVER** place the **Arzum Mixset Plus Hand Blender Set** over or near direct heat sources such as hot gas, electric burner, or heating oven.

- Do not let cord hang over edge of a table or counter, or touch any other appliances.



- When carrying or washing, take care to hold the mixing and cutting blades of your appliance from the correct side, as they are very sharp. Otherwise, they may cause serious injuries.

- Avoid from touching any moving parts when in use. Do not keep your hands, hairs, clothes, or any tools closer.

- Do not use the appliance for breaking too stiff materials into pieces. For example, breaking ices, etc.

- **NEVER** attach to your device any accessories belonging to other appliances.

- Avoid actions that may harm or damage the cord or plug of your device. Do not carry your appliance by holding from the cord. To unplug, hold the plug and **NEVER** pull by the cord.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner, such as by dropping down, etc. Do not attempt to repair it by yourself. Call immediately an **Arzum Authorized Service**.

- **ALWAYS** unplug from outlet when not in use, or before putting in or taking out accessories, or during maintenance and cleaning.

- **NEVER** operate your **Arzum Mixset Plus Hand Blender Set** in an empty container or outdoors. This may cause damaging to your device.

- Use your appliance as recommended.

## WARNING

THIS APPLIANCE HAS BEEN DESIGNED TO OPERATE CONTINUOUSLY FOR 10 SECONDS MAXIMUM. MAKE SURE NOT TO EXCEED SUCH DURATION WHEN PREPARING FOODS. OTHERWISE, THIS MAY CAUSE DAMAGING TO YOUR APPLIANCE.

ALLOW TO COOL DOWN FOR 1 MINUTE PER ONE-TIME OPERATION OF 10 SECONDS.

## SUGGESTIONS OF USE

- Rinse the accessories of your **Arzum Mixset Plus Hand Blender Set** before using for the first time.

- **ALWAYS** keep the cutting blades of your appliance inside of the cutting receptacle when not in use.



## Mixing & Grinding With Hand Blender

- Mount the metal grinding and mixing accessory to the main body by turning until it fits well in its place, without tightening too much.

- Connect the mains plug to the wall socket.

- Use special measuring receptacle and a deep pot in order to obtain the best results from your hand blender and to prevent the material from spreading out.

- **NEVER** operate your appliance with an empty container or outdoors.

- Cut the materials into small pieces and move such pieces up and down through depressing the operation button of your hand blender:



- Never use your hand blender by pushing it hardly on the material to be used.

- By using metal grinding and mixing accessory of your **Arzum Mixset Plus Hand Blender Set** you can prepare sauces, milks, fruit juices, soups, cocktails, and milkshakes; make cooked vegetables, fruits, and milkshakes; make cooked vegetables, fruits, and mashed potatoes (for example, baby foods, etc.); mix such soft materials as butter, eggs, flours, and liquid oils (to make mayonnaise, omelets, dessert, and dough), and mix any foods being cooked in the oven.



- As soon as after you have finished your work clean the metal grinding and mixing accessory and wipe dry with a damp cloth.



## WARNING

- Turn on your appliance only after the ingredients are put into it, and NEVER take any materials out of the unit unless it completely stops.

## Beating & Mixing With Beater Legs

• You can easily make such mixtures as pound cakes, omelets, pancake dough, mayonnaise, by using the beating accessories of your **Arzum Mixset Plus Hand Blender Set**.

• In order to use beater accessories, first mount the beaters by pushing until you make sure that such legs are properly fixed on their place.

• Attach the beater adapter to the motor block, without tightening too much.

• Insert your hand blender in the upright position into a mixing and deep vessel in which you put materials previously, and depress the operation button, then move the appliance circularly inside of the materials.

• Never apply much pressure on your appliance.

• After each use **ALWAYS** dismantle the beaters from the beater adapter, and wash them using water with detergent.

• **NEVER** immerse the beater adapter in water; it would be sufficient to wipe dry with a damp cloth. Leakage of excessive water into the accessory may result in malfunctions.



## WARNING

- 1- Always operate your hand blender in upright position.
- 2- NEVER use your appliance in an empty container or outdoors.
- 3- Do not press your device onto the materials hardly.
- 4- Never immerse the main body of the blender in water.

## Cutting With Bowl

• Using the cutting accessory with a capacity of 700 ml. of your **Arzum Mixset Plus Hand Blender Set** you can cut any foods easily and practically.

• Locate the cutting blades of your appliance onto the shaft in the middle part of the case.



• Place the foods to be cut inside of the case, ensuring that the foods will be of the equivalent level and without piling up.

• Put the cutter adapter of your device onto the case, ensuring to insert in the slot located on the claws in the adapter:

• Place the motor body of your hand blender in its slot located on the adapter, without tightening too much.



• Start the process by depressing the operation button located on the main body.

• Once you have finished your work, rinse the bowl and double sided stainless steel blade with water and detergent, and store the blade in the bowl.

• **NEVER** immerse the cutter adapter in water: Wipe the outside with a damp cloth.

## WARNING

1- **NEVER** operate your **Arzum Mixset Plus Hand Blender Set** unless the main body is attached to the cutter adapter:

2- Do not lift the main body from its slot unless the motor fully stops.

3- Store the cutting blades in the bowl, since they are very sharp.

## CARE & CLEANING

In order to ensure many years of proper operation, due care and cleaning of your **Arzum Mixset Plus Hand Blender Set** will be too easy and short.

• Ensure that the mains plug is disconnected from the wall socket before cleaning the unit, and allow it to cool down for a while.

• It is very important for you to rinse the accessories immediately after using, so that the overall cleaning of the appliance can be easier:

**Motor (Main body):** NEVER immerse into water or other liquids. Wipe the outside with a slightly damp cloth and then dry thoroughly.



**Metal Grinder and Mixer:** Rinse using tepid water and soap. When cleaning under running water, take care not to leak any water into the slot on which the motor is located. If water leaks into the slot, immediately turn upside down and shake it out, and then allow it to cool down with the blade in the upright position.



**Beater Adapter:** NEVER immerse into water or other liquids. Wipe the outside with a slightly damp cloth and then dry thoroughly.



**Cutter Adapter:** NEVER immerse into water or other liquids. Wipe the outside with a slightly damp cloth and then dry thoroughly.



You can wash the measuring beaker, bowl, double sided stainless steel cutting blades, and beaters of your **Arzum Mixset Plus Hand Blender Set** by using water and soap, or in the upper section of a dishwasher. Repeat the same steps after each use.

**Product life 7 years**

**Technical Specifications**

550 W

220-240 V ~ 50/60 Hz

**The product is in compliance with the EEE Directives.**

**WEEE**

This product contains recyclable materials that compliance with the WEEE directives. Do not dispose this product as unsorted municipal waste. Please contact your local municipality for the nearest collection point.



**CE**

**Manufacturer / Importer:**

**Arzum Elektrikli Ev Aletleri San. ve Tic. A.Ş.**  
Otağçılar Caddesi No: 78 Kat: 1 B Blok No: B1b  
Eyüp 34050 İstanbul Türkiye

Made in Turkey

Tel: +90 212 467 80 80 Fax: +90 212 467 80 00

**www.arzum.com**

arzum@arzum.com

## GARANTİ ŞARTLARI

1. Garanti süresi, malın teslim tarihinden itibaren başlar ve 3 yıldır.
2. Malın bütün parçaları dahil olmak üzere tamamı garanti kapsamındadır.
3. Malın ayıplı olduğunu anlaşılmaması durumunda tüketicisi, 6502 sayılı Tüketicinin Korunması Hakkında Kanununun 11 inci maddesinde yer alan;

a- **Sözleşmeden dönme,**

b- **Satış bedelinden indirim isteme,**

c- **Ücretsiz onarılmasını isteme,**

ç- **Satılanın ayıpsız bir misli ile değiştirilmesini isteme,**

**haklarından birini kullanabilir.**

4. **Tüketicinin bu haklardan ücretsiz onarım hakkını seçmesi** durumunda satıcı; işçilik masrafı, değiştirilen parça bedeli ya da başka herhangi bir ad altında hiçbir ücret talep etmeksizin malın onarımını yapmak veya yaptırmakla yükümlüdür. Tüketicisi ücretsiz onarım hakkını üretici veya ithalatçıya karşı kullanabilir. Satıcı, üretici ve ithalatçı tüketicinin bu hakkını kullanmasından müteselsilen sorumludur.

5. Tüketicinin, **ücretsiz onarım hakkını** kullanması halinde malın;

- Garanti süresi içinde tekrar anızalanması,

- Tamiri için gereken azami sürenin aşılması,

- Tamirinin mümkün olmadığının, yetkili servis istasyonu, satıcı, üretici veya ithalatçı tarafından bir raporla belirlenmesi durumlarında;

**tüketicisi malın bedel iadesini, ayıp oranında bedel indirimini veya imkan varsa malın ayıpsız misli ile değiştirilmesini** satıcıdan talep edebilir. Satıcı, tüketicinin talebini reddedemez. Bu talebin yerine getirilmemesi durumunda satıcı, üretici ve ithalatçı müteselsilen sorumludur.

6. Malın tamir süresi **20 iş gününü**, binek otomobil ve kamyonetler için ise **30 iş gününü** geçemez. Bu süre, garanti süresi içerisinde mala ilişkin anızanın yetkili servis istasyonuna veya satıcıya bildirim tarihinde, garanti süresi dışında ise malın yetkili servis istasyonuna teslim tarihinden itibaren başlar. Malın anızasının **10 iş günü** içerisinde giderilememesi halinde üretici veya ithalatçı; malın tamiri tamamlanıncaya kadar; benzer özelliklere sahip başka bir malı tüketicinin kullanımına tahsis etmek zorundadır. Malın garanti süresi içerisinde anızalanması durumunda, tamirde geçen süre garanti süresine eklenir.

7. Malın kullanma kılavuzunda yer alan hususlara aykırı kullanılmasında kaynaklanan anızalar garanti kapsamı dışındadır.

8. Tüketicisi, garantiden doğan haklarının kullanılması ile ilgili olarak çıkabilecek uygunsuzluklarda yerleşim yerinin bulunduğu veya tüketicisi işleminin yapıldığı yerdeki **Tüketicisi Hakem Heyetine veya Tüketicisi Mahkemesine** başvurabilir.

9. Satıcı tarafından bu **Garanti Belgesinin** verilmesi durumunda, tüketicisi **Gümrük ve Ticaret Bakanlığı Tüketicinin Korunması ve Piyasa Gözetimi Genel Müdürlüğüne** başvurabilir.

**MİXSET PLUS**  
AR 1002 ÇUBUK BLENDER SETİ

**ARZUM**®

## GARANTİ BELGESİ

BELGE NO: 0006

BELGE ONAY TARİHİ: 02/07/2014

**İMALATÇI FIRMA**

UNVAN : ARZUM ELEKTRİKLI EV ALETLERİ SAN. VE TIC. A.Ş.

ADRES : OYAKÇILAR CADDESİ NO: 78 KAT: I B BLOK NO: B1b  
34050 EYÜP-İSTANBUL

TEL : (0212) 467 80 80 FAKS: (0212) 467 80 00

E-POSTA :

**FIRMA YETKİLİ İMZASI:**

**ARZUM ELEKTRİKLI  
EV ALETLERİ SAN. VE TIC. A.Ş.**

ÜRÜNÜN CINSİ : BLENDER

MARKASI : ARZUM

MODELİ : MİXSET PLUS

TYPE NO : AR 1002

BANDROL VE SERİ NO :

TESLİM TARİHİ VE YERİ :

GARANTİ SÜRESİ : 3 YIL

AZAMI TAMİR SÜRESİ : 20 İŞ GÜNÜ

**SATICI FIRMA**

UNVAN :

ADRES :

TEL - FAKS :

E-POSTA :

FATURA TARİH VE NO :

TESLİM TARİHİ VE YERİ :

TARİH, İMZA VE KAŞE :

Bu belgenin kullanılmasına; 6502 sayılı Tüketicinin Korunması Hakkında Kanun ve bu Kanun'a dayanılarak yürürlüğe konulan Garanti Belgesi Uygulama Esaslarına Dair Tebliğ uyanca, Gümrük ve Ticaret Bakanlığı Tüketicinin Korunması ve Piyasa Gözetimi Genel Müdürlüğü tarafından izin verilmiştir.

ARZUM®

ARZUM DANIŐMA MERKEZİ

**444 1 800**

GENEL DAĐITICI

**ARZUM ELEKTRİKLİ EV ALETLERİ SAN. VE TİC. A.Ő.**

Otakçılar Caddesi No: 78 Kat: I B Blok No: B1b

Eyüp 34050 İstanbul Türkiye

Tel: (0212) 467 80 80 Faks: (0212) 467 80 00

[www.arzum.com](http://www.arzum.com) [arzum@arzum.com](mailto:arzum@arzum.com)

AR1002-030714

CE